K'nex


8504

MOTORIZED MODELS
Building Set

7+

1051 86





Motor



MOTORIZED MOVEMENT!

⚠ WARNING:

CHOKING HAZARD – Toy contains a small ball and small parts. Not for children under 3 years.



BONUS VALUE! 35

Additional Builds!



522Additional Pieces!






K'nexBuilding Basics

Start Building


Look at the pictures, find the pieces in your set that match and then connect them

together. Try to face your model in the same direction as the instructions while you build. The arrows show you where the parts connect, but not all connection points have arrows. Faded colors show you this section is already built.




Connectors

Push these special connectors togethe tightly until you hear a "click".













Spacers

Be sure to use the correct color and number of spacers shown.



CONTENTS

APPLE	
WRENCH	
BRIDGE	6
COW	
SCORPION	8
TRI-WHEELER	9
CARTWHEELER	10
MUDFISH	11
SCOOTER	13
FAN	15
TRACTOR	16
ROBOT	19
DRILL	
BUS	23
FERRIS WHEEL	27
COMBO HELICOPTER	
BUILDING IDEAS	



Battery Information

How to Insert and Remove Batteries

Use a small Phillips head screwdriver to loosen the screw. Insert 2 fresh AA (LR6) batteries [not included] into the compartment with the correct polarity (+/-) as shown here.

Install batteries before building models.

CAUTION: To Avoid Battery Leakage

- Insert batteries with correct polarity (+/-) as shown.
- Do not mix different types of batteries.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries.

- Do not mix new and used batteries. Only batteries of the same or equivalent type recommended should be used.
- Remove exhausted batteries from the toy; do not short circuit supply terminals.
- Remove all batteries if the toy will not be used for a long period of time.

Important Tips

- · Alkaline batteries are recommended.
- · Rechargeable batteries are not recommended.
- Remove rechargeable batteries before recharging; they must be charged only under adult supervision.
- Non-rechargeable batteries must not be recharged.
- Keep components free of dust; do not immerse or use in water.
- Do not dispose of batteries in a fire; they could leak or explode and cause injury.


WARNING: CHOKING HAZARD


Toy contains a small ball and small parts. Not for children under 3 years.


CAUTION: Keep hands, face, hair and clothing away from all moving parts.


Parts List


Be sure to compare the parts in your set with the parts list here. If anything is missing, please visit www.Basicfun.com to contact us. We are here to help you!



















































































































































Intermediate 60 Model

15211*



@knex f facebook.com/knex

©2020 Basic Fun, Inc., 301 Yamato Road, Suite 4200, Boca Raton FL 33431, USA. All rights reserved. K'NEX and STEAMagination are registered trademarks and the Basic Fun logo is a trademark of Basic Fun, Inc.

Product & colors may vary. Most models can be built one at a time.

WARNING: CHOKING HAZARD – Toy contains a small ball and small parts. Not for children under 3 years.

Mega Motorcycle



*Sold separately



185043-V1-4/20